


## Cerradura de combinación



### INSTRUCCIONES

La combinación original es 0-0-0. Para poner la suya, siga estas instrucciones:


1. Mueva las ruedas del dial (b) a la posición original 0-0-0.
2. Desplace el botón de apertura (a) en la dirección de la flecha y manteniendo esa posición, ruede los diales (b) hasta seleccionar la contraseña deseada.
3. Suelte el botón de apertura (a) para guardar la contraseña.

Ahora estaría ajustada su combinación. Recuerde memorizarla. Repita estos pasos cuando quiera reajustar su combinación.

**Precaución:** No manipular la numeración de los diales y la cerradura al mismo tiempo sin seguir los pasos indicados, puede bloquearse la cerradura.

En caso de bloqueo de la cerradura, debe comprobar todas las combinaciones numéricas posibles.

## Combination Lock



### INSTRUCTIONS

The original number is 0-0-0. To set your own password, please follow these steps:

1. Put the dials (b) at its original numbers 0-0-0.
2. Move the opening button (a) in the direction of the arrow and, keeping that position, roll the dials (b) until the desired password is selected.
3. Release the open button (a) to save the password.

Now you have finished to set your own password. Please remember your password by heart. Please repeat the above steps to reset the numbers.

**Caution:** Do not manipulate the numbering of the dials and the lock at the same time without following the steps indicated, the lock may lock.

In case of blocking, you should check all possible number combinations.